


Cabeça Roscada - RDKW

Categorias

• Z



Ref.	Descrição	ØD	ØD1	L	MD	Z
582100016RD07M8	Cabeça Roscada 16-RD07-M8-02	16	15	25	8	2
582100016RD07M8	Cabeça Roscada 16-RD07-M8-03	16	15	25	8	3
58210020RD07M10	Cabeça Roscada 20-RD07-M10-03	20	19	30	10	3
58210025RD07M12	Cabeça Roscada 25-RD07-M12-03	25	24	35	12	3
58210020RD10M10	Cabeça Roscada 20-RD10-M10-02	20	19	30	10	2
58210025RD10M12	Cabeça Roscada 25-RD10-M12-02	25	24	35	12	2
58210032RD10M16	Cabeça Roscada 32-RD10-M16-03	32	30	45	16	3
58210032RD16M16	Cabeça Roscada 32-RD16-M16-02	32	30	45	16	2